
ELECTROMAGNETIC COMPATIBILITY HANDBOOK

KENNETH L. KAISER



CRC PRESS

Boca Raton London New York Washington, D.C.

Contents

1	EMI Sources	
1.1	Industrial Noise Sources.....	1-1
1.2	Office Noise Sources.....	1-1
1.3	Residential Noise Sources.....	1-1
1.4	Holiday Noise Sources.....	1-2
1.5	Natural Noise Sources.....	1-2
1.6	Automobile Noise Sources.....	1-2
1.7	RF Electromagnetic Sources in the Spectrum.....	1-2
1.8	Noise, Interference, and Unwanted Signals.....	1-2
2	Decibel and Approximations	
2.1	RMS vs. Maximum Amplitude.....	2-1
2.2	Relative Decibels.....	2-2
2.3	Electric Field, Magnetic Field, and Power Density dB Conversions.....	2-3
2.4	Adding dB to dBm.....	2-4
2.5	Adding dB to dBmV.....	2-5
2.6	Adding dB to dBmA.....	2-5
2.7	Negative dB.....	2-6
2.8	Significance of 3 dB and 5 dB.....	2-6
2.9	Significance of 6 dB and 10 dB.....	2-7
2.10	Is dB Power or Voltage Gain?.....	2-8
2.11	dB Version of Equations.....	2-9
2.12	dB Multiplication.....	2-9
2.13	Adding dBmV to dBmV.....	2-10
2.14	dB Approximations.....	2-10
2.15	Signal Sources and Unmatched Loads.....	2-10
2.16	Common Approximations.....	2-11
3	Electrical Length	
3.1	Electrical Length vs. Physical Length.....	3-1
3.2	Standing Waves.....	3-2
3.3	Antenna Effects and Effective Permittivity.....	3-3
3.4	Unshielded Conductor Radiation.....	3-5
3.5	PCB Trace Radiation.....	3-5
3.6	Electrically-Large Car.....	3-5
3.7	Properties of Electrically-Small Metallic Objects.....	3-6

4	Fast Bode Magnitude Plotting	
4.1	Quickly Sketching a Bode Plot.....	4-1
4.2	A Real Function.....	4-10
4.3	The Spectrum of Common Functions.....	4-13
4.4	Equations for the Spectral Magnitude.....	4-14
4.5	Expression from the Bode Plot.....	4-17
4.6	Common Improper Standard Forms.....	4-19
4.7	The Other Bode Plot: The Phase Plot.....	4-21
5	Skin Depth, Wire Impedance, and Nonideal Resistors	
5.1	Eddy's Currents.....	5-1
5.2	The Value of a dc Resistance Measurement.....	5-2
5.3	Skin Depth for Round Wires.....	5-2
5.4	Rectangular vs. Circular Wires.....	5-6
5.5	High-Frequency Resistance Formula.....	5-8
5.6	Importance of the Skin Depth when $\delta > r_w$ and Litz Wire.....	5-8
5.7	Inductance Dominating over Resistance.....	5-12
5.8	Wire Gauge and Cross-Sectional Area.....	5-12
5.9	Importance of Skin Depth in House Wiring.....	5-15
5.10	Stranded and Solid Wire.....	5-16
5.11	Aluminum Wire in a House.....	5-17
5.12	When is the Internal Inductance Important?.....	5-19
5.13	Adjusting a Transformer Tap to Compensate for Line Drop.....	5-20
5.14	Power Loss in Speaker Wire.....	5-21
5.15	Impedance of a Grounding Jumper Wire.....	5-23
5.16	The Resonance of a Resistor.....	5-25
5.17	Resistor Acting Like a Capacitor or an Inductor.....	5-27
5.18	Resistors without an Impedance Peak.....	5-30
5.19	A Resistor Cage.....	5-32
5.20	Resistor Types.....	5-34
5.21	Exotic Audio System Interconnect Cable.....	5-35
6	Nonideal Capacitors and Inductors	
6.1	Realistic Range of Impedances.....	6-1
6.2	Model of a Practical Capacitor.....	6-2
6.3	Model of a Practical Inductor.....	6-4
6.4	Resonant Frequency of a Practical Capacitor.....	6-5
6.5	Resonant Frequency of a Practical Inductor.....	6-6
6.6	Resistive Region of a Capacitor.....	6-7
6.7	Resistive Region of an Inductor.....	6-9
6.8	ESR Determination.....	6-12
6.9	Maximum Q of an Iron-Core Inductor.....	6-13
6.10	Why Place Two Different Capacitors in Parallel?.....	6-16

6.11	Capacitor Types	6-20
6.12	Choosing the Right Capacitor	6-23
6.13	Inductor Types	6-23
6.14	Impedance Summary	6-25

7 Passive Filters

7.1	Filters	7-1
7.2	Low-Pass Capacitor Filter	7-3
7.3	High-Pass Capacitor Filter	7-5
7.4	Low-Pass Inductor Filter	7-6
7.5	High-Pass Inductor Filter	7-8
7.6	Low-Pass <i>RC</i> Filter	7-9
7.7	Low-Pass <i>LC</i> Filter	7-13
7.8	Low-Pass <i>CL</i> Filter	7-16
7.9	High-Pass <i>LC</i> and <i>CL</i> Filters	7-19
7.10	Series Band-Pass Filter	7-21
7.11	Shunt Band-Pass Filter	7-27
7.12	Band-Reject Filters	7-30
7.13	Low-Pass π Filter	7-34
7.14	High-Pass π Filter	7-38
7.15	Low-Pass T Filter	7-41
7.16	High-Pass T Filter	7-43
7.17	Filter Comparisons	7-44
7.18	<i>RC</i> Filter Comparisons	7-49
7.19	More <i>RC</i> Filters	7-53
7.20	Maximum Possible <i>Q</i>	7-53
7.21	High- <i>Q</i> Circuit Conversions	7-58
7.22	<i>Q</i> Selection for Filters	7-62
7.23	Series and Parallel <i>RLC</i> Circuit Properties	7-70
7.24	Measuring the <i>Q</i> of a Crystal	7-86
7.25	Distorting a Signal	7-95
7.26	Passive vs. Active Filters	7-100
7.27	Insertion Loss	7-101
7.28	Insertion Loss and <i>Q</i>	7-103
7.29	Filtering at High-impedance Levels	7-108
7.30	Filtering on $\lambda/2$ Transmission Lines	7-108
7.31	Impedance “Matching” with Passive Filters	7-109
7.32	Three-Terminal Capacitor	7-127
7.33	Feed-Through Capacitor	7-128

8 Cable Modeling

8.1	Purpose of a Cable	8-1
8.2	High-Fidelity Speaker Wire Candidates	8-3

8.3	Selecting the Cable Model	8-6
8.4	Failure of the Lumped-Circuit Model	8-10
8.5	Characteristic Impedance	8-10
8.6	Characteristic Impedance of a dc Power Bus	8-14
8.7	Reducing the Characteristic Impedance	8-20
8.8	Influence of Dielectric Constant	8-20
8.9	Coax and Twin-Lead.....	8-21
8.10	Thinly Coated Twin-Lead	8-25
8.11	Beads in Coax	8-30
8.12	Dielectric Resistance and Insulators	8-31
8.13	Cable Capacitance and Audio Cables	8-33
8.14	Grounding Strap Impedance.....	8-34
8.15	ESD Signal Wire Guideline.....	8-40
8.16	Twisted Pair.....	8-42
8.17	When the Line Can Be Ignored.....	8-45
8.18	Line Resonance	8-46
8.19	Multiple Receiver Loading.....	8-47
8.20	Proximity Effect	8-50
8.21	Characteristic Impedance Formula.....	8-52

9 Transient Behavior in the Time Domain

9.1	Transient vs. Sinusoidal Steady State	9-1
9.2	A Time-Delay Circuit	9-2
9.3	An RC Integrator.....	9-6
9.4	An RC Differentiator	9-8
9.5	A More General RC Circuit.....	9-11
9.6	Static Charge Buildup	9-14
9.7	Current Surges and Capacitor Dividers.....	9-18
9.8	Compensation, General Voltage Divider, and Multiple Capacitors	9-22
9.9	Multiple-Supply RC Circuits.....	9-26
9.10	RC Rise Time and Speed.....	9-31
9.11	Measuring the Time Constant.....	9-32
9.12	Energy and Power in RC Circuits	9-34
9.13	The Inductive Kick.....	9-37
9.14	RL vs. RC Differentiators and Integrators	9-40
9.15	Inductive Load Switching, Release Time, and Rise Time	9-41
9.16	dc Biasing an Inductor and Inductive Energy	9-45
9.17	Inductive vs. Capacitive Circuits.....	9-48
9.18	Series and Parallel RLC Circuits	9-49
9.19	Ringling as a Function of Q.....	9-54
9.20	Ringling and Resonant Frequency	9-59
9.21	Digital Signal Ringling	9-60
9.22	Effect of the Energy Content of the Input Signal on Ringling.....	9-61
9.23	Oscillation Burst—The Ringling Circuit	9-62

9.24	Shunt Peaking to Reduce the Rise Time	9-68
9.25	Other Two Energy-Storage Element Circuits.....	9-73
9.26	Double-RC Lumped Interconnect Model	9-75
9.27	Advanced RLC Circuit.....	9-80
9.28	More Overshoot, Settling Time, and Ringing Frequency.....	9-83

10 Air Breakdown

10.1	Breakdown Voltage.....	10-1
10.2	Glows, Arcs, Coronas, and Sparks	10-4
10.3	Nonuniform Fields and Time-Varying Arc.....	10-5
10.4	Ideal Switching of Simple Loads	10-8
10.5	Ideal Switching of Complex Loads.....	10-11
10.6	Switching and Breakdown	10-16
10.7	Showering Arc.....	10-18
10.8	Speed of Switching	10-18
10.9	Suppressing the Breakdown	10-19
10.10	Switch Network Example	10-26
10.11	Arc Suppression with Resistive Loads.....	10-30
10.12	Arc Suppression with Capacitive Loads.....	10-31
10.13	Arc Suppression with Inductive Loads	10-33
10.14	Sparking at Very Low Voltages?	10-38
10.15	Switch Corrosion and Erosion	10-39
10.16	Maximum Electric Field and Breakdown Table.....	10-44
10.17	Minimum Corona Voltage	10-58
10.18	Voltage Rating of Coax.....	10-62
10.19	Solutions to Poisson's Equation.....	10-65
10.20	Arcing in a Silo	10-72
10.21	All of the Electric Field Boundary Conditions	10-78
10.22	Powder Bed	10-91
10.23	The Field from Corona.....	10-93

11 Transient Behavior in the Frequency Domain

11.1	What Is the Laplace Transform?	11-1
11.2	Properties of the Laplace Transform.....	11-6
11.3	Massive Laplace Transform Table.....	11-41
11.4	The Step Function	11-46
11.5	The Impulse Function	11-55
11.6	The Impulse Response, Step Response, and Transfer Function.....	11-68
11.7	Modeling a Real Inductor Using a Current Ramp.....	11-75
11.8	Sinusoidal Steady State with Transforms	11-77
11.9	Initial Capacitor Voltages and Initial Inductor Currents	11-79
11.10	Voltage Zapper	11-84
11.11	Blimp Amplitude.....	11-88

11.12	Audio Filter Response.....	11-91
11.13	Half-Wave Rectifier	11-93
11.14	The Power of the Laplace Transform.....	11-97

12 Spectra of Periodic and Aperiodic Signals

12.1	Time and Frequency Viewpoints and Periodicity.....	12-1
12.2	The Marvelous Fourier Series.....	12-6
12.3	Fourier Series Forms for Periodic Signals and their Spectra	12-12
12.4	Success of the Fourier Series Approximation.....	12-104
12.5	Fourier Series Table	12-107
12.6	Converting between the Various Fourier Forms.....	12-107
12.7	Using the Table to Determine Other Series.....	12-112
12.8	Last Resort: Using the Definition to Determine the Fourier Series	12-133
12.9	Fourier Series Shortcuts via Symmetry.....	12-140
12.10	Circuit Analysis Using the Fourier Series	12-142
12.11	Amplitude Spectrum of a Digital Waveform	12-155
12.12	20X Guideline for Digital Waveforms	12-159
12.13	Doubling the Frequency and Halving the Rise Time.....	12-161
12.14	Fourier and Laplace Transforms — Necessary Tools for Understanding Aperiodic Signals.....	12-165
12.15	Obtaining the Fourier Transform via Properties, the Laplace Transform, and the Fourier Series	12-167
12.16	Spectrums of Aperiodic Signals.....	12-181
12.17	Smoothness and Amplitude Spectrum	12-185
12.18	Highest Frequency of Interest of a Digital Waveform	12-188
12.19	Double-Exponential Pulse.....	12-193
12.20	Modeling a Stroke of Lightning	12-194
12.21	Spectrum of Double-Exponential Pulse	12-197
12.22	Energy in a Double-Exponential Pulse.....	12-198
12.23	Using Just the Rise Time.....	12-200
12.24	Many Delay and Rise Times	12-203
12.25	Effective Rise Time of Systems in Cascade	12-225
12.26	Impulse Responses of Many Systems in Cascade.....	12-230
12.27	Many Bandwidths	12-233
12.28	Time-Bandwidth Product	12-239
12.29	Consequence of Ripple in the Frequency Domain	12-243
12.30	Frequency-Domain or Time-Domain Testing?	12-245

13 Transmission Lines and Matching

13.1	Voltage Reflection and Transmission Coefficients	13-1
13.2	Impedance Mismatch	13-2
13.3	VSWR and SWR.....	13-3
13.4	The Cost of a VSWR > 1.....	13-7

13.5	Distinguishing between the Load and Source	13-8
13.6	Transient and Steady-State Input Impedance	13-9
13.7	Transient Reflections	13-11
13.8	Matching at the Receiver and its Cost	13-13
13.9	Shunt Matching with Distributed Receivers	13-15
13.10	Microstrip Branching.....	13-16
13.11	Shunt Diode Matching	13-18
13.12	Shunt RC Matching	13-19
13.13	Matching at the Driver and its Cost.....	13-23
13.14	Series Matching with Multiple Receivers.....	13-25
13.15	Effects of Nonzero Source and Load Reflection Coefficients.....	13-28
13.16	Signal Bounce as a Function of Time.....	13-29
13.17	Settling Time	13-30
13.18	Settling Time vs. Reflection Coefficient.....	13-32
13.19	Receiver Voltage when Rise Time = Line Delay	13-33
13.20	Receiver Voltage when Rise Time \ll Line Delay	13-35
13.21	Receiver Voltage when Rise Time \gg Line Delay	13-37
13.22	Advanced Transient Problem.....	13-38
13.23	Ringing in Lumped Circuits.....	13-42
13.24	More Shunt Matching	13-42
13.25	Shunt Matching with a Split Termination for a TTL System.....	13-44
13.26	Shunt Matching with a Split Termination for a CMOS System.....	13-47
13.27	Shunt Matching with a Split Termination for an ECL System.....	13-47
13.28	Split-Termination Equivalent	13-49
13.29	Experimentally Determining the Line Impedance.....	13-50
13.30	Series Matching and Dynamic Output Resistance	13-51
13.31	Driver Current for Series and Shunt Matching.....	13-54
13.32	Summary of Matching Methods	13-55
13.33	Relationship Between Sinusoidal Input and Output Voltage.....	13-56
13.34	The Sinusoidal Current Expression	13-60
13.35	The Sinusoidal Input Impedance	13-62
13.36	Coaxial Cable Branching	13-65
13.37	“Y” Splitter for “Hair-Ball” Networks	13-67
13.38	Stub Tuning.....	13-69
13.39	Inductive Loading	13-75
13.40	Low-Loss Lines and Short Lines.....	13-79
13.41	Inductive Line	13-84
13.42	Capacitive Line.....	13-87
13.43	The Lossy Expressions for Sinusoidal Steady-State.....	13-89
13.44	Telephone Lines and the “ RC ” Region.....	13-91
13.45	Transmission Line Parameter Expressions.....	13-95
13.46	S Parameters.....	13-99
13.47	Using the Sinusoidal Reflection Coefficient for Transient Problems	13-105
13.48	Effect of Receiver Capacitance on Transient Behavior	13-106

13.49	Complete Reflection due to Excessive Capacitance.....	13-107
13.50	Amplitude of Mismatch “Blimp” from Receiver Capacitance.....	13-107
13.51	When not to Match!.....	13-110

14 Passive Contact Probes

14.1	Low-Impedance Passive Probe.....	14-1
14.2	Improved Model of the Low-Impedance Passive Probe.....	14-2
14.3	Operating Range of the Low-Impedance Passive Probe.....	14-4
14.4	Improved Model of the Cable and Scope.....	14-4
14.5	High-Impedance Passive Probe.....	14-7
14.6	Input Impedance of a High-Impedance Passive Probe.....	14-9
14.7	High-Impedance Probe Compensator.....	14-10
14.8	Testing with a Square Wave.....	14-13
14.9	Effect of Inductance on the Probe.....	14-17

15 Inductance, Magnetic Coupling, and Transformers

15.1	Inductance.....	15-1
15.2	Equivalent Inductance.....	15-2
15.3	Winding Direction and the Dot Convention.....	15-4
15.4	Modeling the Inductance of Two Parallel Strips.....	15-6
15.5	Modeling the Inductance of a Loop Near a Wire.....	15-7
15.6	Changing Inductance via Magnetic Coupling.....	15-8
15.7	Different Currents but Identical Voltages.....	15-12
15.8	Useful Properties of Parallel Inductors.....	15-13
15.9	Grounding Strap Inductance.....	15-18
15.10	Multiple Conductor Grounding Straps.....	15-26
15.11	Reducing PCB Land Inductance.....	15-31
15.12	Typical Mutual Inductance of Wire.....	15-33
15.13	Lead Position on Capacitors.....	15-35
15.14	The Many Inductances and the “Sniffer”.....	15-38
15.15	Optimum Loop Dimensions.....	15-46
15.16	Pickup Loop Loading Down the Circuit.....	15-48
15.17	Inductance Formula.....	15-51
15.18	Ideal Transformers Operating in Sinusoidal Steady State.....	15-57
15.19	Typical Ideal Transformer Problems.....	15-62
15.20	RF Tuning.....	15-70
15.21	Behavior of a Nonideal Transformer.....	15-74
15.22	Linear Transformer Models.....	15-79
15.23	Low-Frequency Model.....	15-81
15.24	Mid-Frequency and Power-Frequency Models.....	15-83
15.25	High-Frequency Model.....	15-85
15.26	Wideband Models.....	15-86
15.27	Multiwinding and Tapped Transformers.....	15-90

15.28	Placing Transformers in Series and Parallel	15-94
15.29	Hybrid Transformers.....	15-97
15.30	Autotransformers.....	15-104
15.31	Transformer Ratings.....	15-110
15.32	Nonlinear In-Rush Current.....	15-112
15.33	Instrument Transformers.....	15-116
15.34	Tuned Transformers.....	15-119
15.35	Some “Other” Transformers	15-138
15.36	Determining All of the Unknowns.....	15-141
15.37	Transient Inputs to Linear Transformers.....	15-151
15.38	Step Input to a Real Step-Up Transformer.....	15-158
15.39	Step Input to a Real Step-Down Transformer	15-166
15.40	When Are Transformers Used?	15-167

16 Magnetic Materials and a Few Devices

16.1	$B = \mu H$	16-1
16.2	Magnetic Circuits.....	16-2
16.3	Toroid vs. Rod.....	16-8
16.4	Common-Mode Choke	16-10
16.5	Ringing and Chokes.....	16-12
16.6	Increasing Inductance with a Bead	16-13
16.7	Relationship between Bead Parameters and Inductance	16-15
16.8	Saturating Ferrite Beads.....	16-17
16.9	How Ferrite Filters Work	16-19
16.10	Loss Factor.....	16-21
16.11	The Hysteresis Curve and the many Permeabilities.....	16-23
16.12	Further Discussion of the Hysteresis Curve	16-33
16.13	Hard vs. Soft.....	16-35
16.14	Survey of Typical Magnetic Properties	16-38
16.15	Demagnetization Field and Magnetic Charge.....	16-41
16.16	Purpose of the Air Gap	16-54
16.17	Force, Torque, and Magnetization Current	16-60
16.18	Free Energy from a Magnet?.....	16-67

17 Baluns and Balanced Circuits

17.1	Definition of Balanced System	17-1
17.2	Voltage Balun	17-2
17.3	Another Voltage Balun	17-6
17.4	Current Balun	17-8
17.5	Another Current Balun.....	17-10
17.6	Why Baluns Do Not Always Work	17-13
17.7	Another Common-Mode Choke Limitation and Shielding a Choke	17-19
17.8	Varying Common-Mode Impedance	17-21

17.9	Excess Cable	17-22
17.10	Location of Choke.....	17-23
17.11	Multiple Cores	17-25
17.12	Why a System Is Never Truly Balanced.....	17-25
17.13	Balancing and Common-Mode Currents.....	17-25
17.14	A Resistive Balanced Circuit.....	17-26
17.15	The Conversion Process	17-27
17.16	CMRR.....	17-29
17.17	Balanced Input Receivers.....	17-32
17.18	Balanced Output Drivers.....	17-36
17.19	Balanced and Single-Ended Drivers and Receivers.....	17-37
17.20	Balanced and Matched.....	17-44
17.21	Common Choke.....	17-47
17.22	Ferrite Beads.....	17-50
17.23	Grounding Coax Outside a House.....	17-51
17.24	Isolation Transformers	17-52
17.25	Single, Double, and Triple Transformer Shielding.....	17-53
17.26	Optoisolators.....	17-58
17.27	Common-Mode and Differential-Mode Impedance.....	17-59
17.28	Transmission Line Baluns	17-63
17.29	Matching π and O Pads.....	17-67
17.30	Matching T and H Pads.....	17-70
17.31	Matching L and U Pads	17-73
17.32	Bridged T and H Pads.....	17-76
17.33	Low-Impedance and High-Attenuation Pads	17-78

18 Cable Shielding and Crosstalk

18.1	Best Cable to Reduce Magnetic Noise	18-1
18.2	Connecting Balanced and Unbalanced Systems.....	18-6
18.3	Bicoaxial Line	18-12
18.4	Reducing Noise Through Transformers.....	18-13
18.5	Modeling a Cable as a Transformer	18-17
18.6	Break Frequency of Coax.....	18-19
18.7	Multiple Grounding Points for Coax.....	18-22
18.8	Keeping Noise off the Shield	18-24
18.9	Switching the Neutral and Hot Wires.....	18-26
18.10	Avoiding Ground Loops and Hum.....	18-27
18.11	Multipoint and Hybrid Grounding	18-31
18.12	Dynamic Range Between Systems.....	18-33
18.13	Multiple Returns in Ribbon Cable.....	18-35
18.14	Loose Wires as a Cable.....	18-38
18.15	Transfer Impedance	18-38
18.16	Loss Impedances and Transfer Admittance	18-48
18.17	The Coupling Model.....	18-54

- 18.18 Pigtails and Connectors—Weak Links in a System..... 18-57
- 18.19 Capacitive or Inductive Crosstalk?..... 18-59
- 18.20 Measurement Tools 18-62
- 18.21 Susceptibility of High and Low Resistances 18-63
- 18.22 Susceptibility of Scopes..... 18-64
- 18.23 Foam Encapsulation 18-65
- 18.24 Inductive Crosstalk and the 3-W Guideline 18-65
- 18.25 Capacitive Crosstalk and the 3-W Guideline 18-69
- 18.26 Long Lines vs. Close Lines..... 18-73
- 18.27 6" Guideline for Telephone Lines..... 18-75
- 18.28 Four-Conductor Trace Layout..... 18-76
- 18.29 377 Ω Guideline 18-81
- 18.30 Why Twisting Often Helps..... 18-83
- 18.31 RC Circuit and Crosstalk..... 18-89
- 18.32 Summary of Methods to Reduce Crosstalk 18-92
- 18.33 Fiber's Weakness..... 18-93

19 Radiated Emissions and Susceptibility

- 19.1 Radiated or Conducted Vehicle Interference?..... 19-1
- 19.2 The Automobile Noise Mystery 19-2
- 19.3 Copper Plane Addition..... 19-6
- 19.4 Emissions from Twin-Lead Line..... 19-7
- 19.5 Differential-Mode Current Emissions from Twin-Lead Line 19-9
- 19.6 Common-Mode Current Emissions from Twin-Lead Line 19-10
- 19.7 Reducing Emission Levels 19-11
- 19.8 Susceptibility of Twin-Lead Line 19-13
- 19.9 Small-Loop and Hertzian Dipole Models..... 19-17
- 19.10 Neglecting the Capacitance and Inductance 19-20
- 19.11 Probe Lead Pickup 19-21
- 19.12 Wave Equation..... 19-25
- 19.13 Susceptibility of Electrically-Long Twin-Lead Line 19-27
- 19.14 Susceptibility of Electrically-Long Wire Above a Ground Plane..... 19-35
- 19.15 Theory of Current Probes..... 19-44
- 19.16 Loaded Current Probe 19-55
- 19.17 Transfer Impedance of Current Probes..... 19-59

20 Conducted Emissions and Susceptibility

- 20.1 Polluted Power Line..... 20-1
- 20.2 Locating Malicious Conducted Interference..... 20-4
- 20.3 Suppressors..... 20-5
- 20.4 LISN's 20-20
- 20.5 Input Impedance of LISN..... 20-24
- 20.6 Maximum Input Impedance of a Network 20-28

20.7	Resonance of LISN with Capacitive and Inductive Loading	20-31
20.8	Separating the Common and Differential	20-34
20.9	Common-Mode and Differential-Mode Filters	20-36
20.10	Nonlinear Evils	20-38

21 Plane Wave Shielding

21.1	The “Magic” of Shielding Waves Revealed	21-1
21.2	The Impedance of a Wave	21-2
21.3	Impedance of Air, Real Metals, and Real Insulators	21-3
21.4	Reflection and Transmission Coefficients	21-7
21.5	Plane Wave Power	21-8
21.6	Single-Layer Conducting Shield	21-11
21.7	Thin Shields and Reflection Loss	21-18
21.8	Thick Shields and Absorption Loss	21-20
21.9	Skin Depth	21-23
21.10	Skin Depth for Good Insulators	21-24
21.11	Skin Depth for Several Good Metals	21-25
21.12	Complex Permittivity and RF Through Human Fat	21-27
21.13	Microwaves through Human Fat	21-30
21.14	Table of Dielectric Constants and Loss Tangents	21-32
21.15	Loss in dB Per Skin Depth	21-33
21.16	Reflection, Absorption, and Multiple-Reflection Losses	21-41
21.17	Effect of Dielectric Constant on Shielding	21-43
21.18	Near Field or Far Field?	21-43
21.19	Wave Impedance	21-48

22 Electric Field Shielding

22.1	The “Magic” of Electric Field Shielding Revealed	22-1
22.2	Size is Important!	22-3
22.3	Shielding Reciprocity?	22-6
22.4	Using Capacitance to Model Shielding	22-8
22.5	Capacitor Shielding	22-10
22.6	Three-Terminal Capacitor	22-12
22.7	Shielding Cans	22-13
22.8	Finite-Conductivity Spherical Bodies	22-19
22.9	Step Response of Spherical Bodies	22-26
22.10	Finite-Conductivity Cylindrical Body	22-27
22.11	Electric Blankets and Infants	22-29
22.12	Typical Electric Field Strengths	22-30
22.13	Current Through and Voltage Across a Field-Immersed Person	22-30
22.14	Insulating Spherical Shields	22-39
22.15	Insulating Cylindrical Shields	22-41
22.16	EQS and Perfect Conductors	22-42

23 Magnetic Field Shielding

23.1	The “Magic” of Magnetic Field Shielding Revealed.....	23-1
23.2	Magnetic Field from Simple Current Distributions.....	23-2
23.3	Magnetic Fields for Other Current Distributions.....	23-16
23.4	Magnetic Field Boundary Conditions.....	23-32
23.5	Flux Shunting Explained via Boundary Conditions.....	23-38
23.6	Self Shielding Nature of Coax.....	23-41
23.7	Method of Images for Currents.....	23-50
23.8	Wire Partners Can Reduce Fields.....	23-54
23.9	Thick Poor Conductors.....	23-62
23.10	Thin Good Conductors.....	23-64
23.11	Spherical and Cylindrical Conducting and Magnetic Shields.....	23-67
23.12	Pure Magnetic Spherical Shell.....	23-76
23.13	Pure Magnetic Cylindrical Shell.....	23-79
23.14	Finite-Length Cylindrical Shell.....	23-82
23.15	Shielding the Source and Shielding Reciprocity.....	23-85
23.16	Shielding a Cosmetologist with a Body Suit.....	23-87
23.17	Power Line Shielding via Burying.....	23-91
23.18	Wave Impedance Concept.....	23-98
23.19	Flat Shielding of Current-Carrying Loops.....	23-103
23.20	Grounding Shields.....	23-105
23.21	Cheap Shielding.....	23-105
23.22	Nonideal Shapes.....	23-106
23.23	Reducing the Magnetic Coupling Between Inductors.....	23-107
23.24	Typical Magnetic Flux Densities.....	23-109
23.25	MQS and Perfect Conductors.....	23-112
23.26	Decoupled Time-Varying Electric and Magnetic Fields.....	23-118

24 Additional Shielding Concepts

24.1	When Is a Shield Flat?.....	24-1
24.2	Performance of a Shielded Room.....	24-3
24.3	Laminated Shields.....	24-5
24.4	Shields with an Air Gap.....	24-8
24.5	Gold Coating on Glass.....	24-17
24.6	Laminates for Magnetic Fields.....	24-21
24.7	Rust Never Sleeps—Corrosion.....	24-32
24.8	Surface Impedance.....	24-34
24.9	Voltage and Current along a Chassis.....	24-40
24.10	Impedance of Coated Conductors.....	24-42
24.11	Nontraditional Shielding Materials.....	24-44
24.12	Shielding Effectiveness vs. Surface Resistance.....	24-47
24.13	Near-Field Electric Shielding Effectiveness.....	24-49
24.14	An Equipotential Surface.....	24-51
24.15	Electric vs. Magnetic Field Measurements.....	24-52

24.16	Single-Conductor Transmission Line.....	24-54
24.17	TEM, TE, and TM Waves.....	24-54
24.18	Cutoff Frequency of a Waveguide.....	24-55
24.19	Attenuation Beyond Cutoff.....	24-59
24.20	Seepage through a Seam.....	24-61
24.21	One Large Hole vs. Several Smaller Holes.....	24-64
24.22	Honeycomb Ventilation Openings.....	24-66
24.23	Coupling through an Aperture.....	24-67
24.24	Radio in a Metal Box.....	24-74
24.25	Lightning Protection Inside an Automobile.....	24-75

25 Test Chambers

25.1	Cage Antenna.....	25-1
25.2	Screen Rooms and OATS's.....	25-7
25.3	Resonant Frequency of a Midsize Car and Notebook Computer.....	25-15
25.4	High or Low Q?.....	25-15
25.5	Abundance of Modes and Mode Degeneracy.....	25-21
25.6	Stirring Up the Fields.....	25-25
25.7	Dark Room.....	25-30
25.8	TEM Cell.....	25-36

26 Floating Metal and Guard Electrodes

26.1	Examples of Floating Metal.....	26-1
26.2	Unused Conductors.....	26-2
26.3	To Ground or Not to Ground Nearby Metal.....	26-3
26.4	Artificially Changing Capacitance and Inductance.....	26-5
26.5	Loose Metal.....	26-10
26.6	Arcing and Floating Metal.....	26-11
26.7	Floating Inputs.....	26-16
26.8	Tube vs. Transistor Multimeter.....	26-18
26.9	The Powerless Voltage.....	26-19
26.10	Standard Bridge Circuit.....	26-19
26.11	Connection to a Floating Bridge.....	26-21
26.12	Irrelevance of Floating a Shield.....	26-23
26.13	Strain Gauge Shielding.....	26-24
26.14	Electronically Reducing Capacitance—The Guard Electrode.....	26-26
26.15	Interference Control with a Guard Shield.....	26-30

27 Electrostatic Discharge

27.1	What is ESD?.....	27-1
27.2	Methods of Charging.....	27-1
27.3	Triboelectric Series.....	27-5
27.4	Microphony.....	27-7

27.5	Voltage and Current Responses	27-11
27.6	Sources of Current	27-14
27.7	Rate of Charge Decay.....	27-18
27.8	Maximum Surface Charge Before Breakdown	27-25
27.9	Grounded Conducting Objects and Charged Insulating Surfaces.....	27-32
27.10	Charge Accumulation Along Interfaces.....	27-45
27.11	Convection Charge Flow	27-52
27.12	Potential of an Insulator’s Surface	27-58
27.13	Electric Field from Simple Charge Distributions.....	27-60
27.14	Electric Field From Other Charge Distributions.....	27-64
27.15	Discharges Classified.....	27-71
27.16	Minimum Ignition Energy	27-76
27.17	Electrostatic Hazard Case Studies	27-81
27.18	Measuring Charge	27-85
27.19	Measuring the Electric Field.....	27-97
27.20	Measuring Voltage	27-105
27.21	Measuring Bulk and Surface Resistivity.....	27-109
27.22	Maximum Body Voltage and Typical Capacitances	27-116
27.23	RLC Discharge Model.....	27-119
27.24	ESD Rules-of-Thumb and Guidelines	27-121
27.25	Raindrop Bursts, P-Static, and Corona Noise.....	27-123
27.26	Locating Weaknesses with a “Zapper”	27-124
27.27	Surround, Ground, and Impound	27-124
27.28	Wrist and Ankle Straps.....	27-125
27.29	Floor Coatings.....	27-126
27.30	Pink, Black, and Shielded Bags.....	27-127
27.31	Static-Dissipative Work Surfaces	27-130
27.32	Sugar Charge Decay	27-136
27.33	Capacitance Measurement for Multiple Conductors	27-141
27.34	Energy and Capacitance.....	27-148
27.35	Capacitance Formula.....	27-152

28 Grounding

28.1	Verbs, Nouns, and Adjectives.....	28-1
28.2	Groundless Devices.....	28-2
28.3	Ground Symbols	28-2
28.4	A “Good” Ground Reference	28-3
28.5	Reasons to Earth Ground	28-3
28.6	Voltage Hazards Involving Ground.....	28-4
28.7	Safe Current and Voltage Levels	28-5
28.8	Transient Shocks	28-10
28.9	Grounding the Neutral Wire in Service Panels.....	28-14
28.10	GFI’s.....	28-16
28.11	IDCIs and the Achilles’ Heel of GFCIs	28-20

28.12	Dangerous Two-Prong Devices.....	28-22
28.13	Pigtail Adapters	28-23
28.14	Safe Leakage Current for an Electric Razor	28-24
28.15	Isolation Transformer.....	28-26
28.16	Resistance Definition	28-29
28.17	Resistance to Ground Formula	28-36
28.18	2.2L Guideline	28-48
28.19	Surface Potentials.....	28-50
28.20	When Lightning Hits	28-56
28.21	The Purpose of Lightning Rods.....	28-59
28.22	Rod Materials	28-60
28.23	Measuring Earth's Resistivity	28-60
28.24	Measuring the Resistance of an Earthing Electrode.....	28-74
28.25	Three-Point Method Again	28-79
28.26	Surge Impedance of an Electrode.....	28-81
28.27	Dedicated Ground in a Plant.....	28-82
28.28	Single-Point vs. Multiple-Point Grounding.....	28-83

29 Circuit Board Layout for EMC

29.1	EMC Overview	29-1
29.2	Immunity or Susceptibility?	29-2
29.3	System Levels.....	29-3
29.4	Introductory Component Layout Concepts.....	29-3
29.5	Single-Layer PCB System Layout	29-5
29.6	Single-Layer PCB Power Distribution System	29-6
29.7	Multilayer Boards.....	29-10
29.8	Board Resonance.....	29-12
29.9	The Flow of Charge Down a Line	29-15
29.10	Printed Circuit Board Trace Configurations.....	29-17
29.11	Decoupling Capacitors	29-21
29.12	More Decoupling Capacitors	29-24

30 Antennas

30.1	Radiation Resistance	30-1
30.2	Radiation Efficiency and Ohmic Losses.....	30-2
30.3	Small Antennas	30-7
30.4	Large Antennas.....	30-11
30.5	Input Impedance.....	30-15
30.6	Directive Gain, Directivity, and Power Gain.....	30-23
30.7	Q and Bandwidth	30-27
30.8	Receiving vs. Transmitting Antenna	30-32
30.9	The Right Antenna.....	30-35
30.10	Wave Orientation.....	30-53

30.11	Objects Close to an Antenna	30-56
30.12	Antenna Factor.....	30-57
30.13	Near-Field H Antennas and Probes	30-59
30.14	Shielded H-Field Probe.....	30-61
30.15	Magnetic-Core Rod Antenna	30-67
30.16	Near-Field E Antennas and Probes	30-73
30.17	Loop vs. Rod Antenna	30-76
30.18	Friis's Formula	30-77
30.19	Fields from a Distant Source	30-79
Appendix A:	Summary of the Three Major Coordinate Systems.....	A-1
Appendix B:	Definitions for Common and Uncommon Functions.....	B-1
Appendix C:	Conversion, Unit, and Notation Tables.....	C-1
Appendix D:	Helpful Mathematical Relationships.....	D-1
References	R-1
Index	I-1