

# **Ground Gas Handbook**

**Steve Wilson, Geoff Card and Sarah Haines**



Whittles Publishing

# Contents

Foreword	ix
<b>1 Introduction</b>	<b>1</b>
1.1 Landfill gas incidents	2
1.2 Are other sources of ground gas a risk?	4
1.3 Radon	5
<b>2 Regulations and policy guidance</b>	<b>6</b>
2.1 Planning Policy Statement 23	6
2.2 Environment Agency policy on development within 250 m of a landfill	8
2.3 Building Regulations Approved Document C (revised edition)	9
2.4 Part 2A of the Environmental Protection Act	10
2.5 Legal requirements for maintenance	11
2.6 Climate change	11
2.7 Waste management	12
<b>3 Sources and properties of ground gases and vapours</b>	<b>14</b>
3.1 Sources of ground gas	14
3.2 History of landfilling	17
3.2.1 Early history	17
3.2.2 Medieval Period	18
3.2.3 The Industrial Revolution	18
3.2.4 Beginning of waste management legislation	19
3.2.5 Early 20th century	19
3.2.6 After the Second World War	20
3.2.7 1970s	20
3.2.8 Control of Pollution Act 1974	21
3.2.9 Environmental Protection Act 1990	22
3.2.10 21st century	23
3.3 Ground gas and vapour properties	24

---

<b>4 Gas and vapour generation and migration</b>	<b>33</b>
4.1 Methane and carbon dioxide generation	33
4.2 Estimating the volume of methane and carbon dioxide that is generated	37
4.3 Generation of minor component gases (trace gases)	39
4.4 Vapour production	41
4.5 Gas and vapour migration	42
4.6 Modelling gas and vapour migration	43
4.6.1 Pressure driven flow	46
4.6.2 Darcy's law	46
4.6.3 Diffusive flow	48
4.6.4 Fick's law	48
4.7 Estimating surface emission rates	52
<b>5 Site investigation and monitoring</b>	<b>56</b>
5.1 Strategy	56
5.2 General guidance	56
5.2.1 Desk study	57
5.2.2 Soil descriptions	57
5.2.3 Gas generation tests	57
5.2.4 Gas monitoring	58
5.3 Measuring ground gas	59
5.3.1 Headspace	59
5.3.2 Soil pore structure	60
5.3.3 Soil permeability	60
5.3.4 Biological reactions	61
5.3.5 Implications for monitoring	62
5.3.6 Gas monitoring instruments	63
5.4 Measuring vapours	63
5.5 Monitoring wells	64
5.5.1 How many?	64
5.5.2 Gas spike surveys and wells in trial pits	66

5.5.3 What diameter monitoring well?	68
5.5.4 How deep should the monitoring wells be?	69
5.6 Monitoring protocols	70
5.6.1 What to monitor?	70
5.6.2 How long to monitor?	72
5.6.3 Examples of using Table 5.3	73
5.7 Flux boxes or chambers	74
5.8 Flame ionisation detectors (FID)	75
5.9 Specialist testing	75
5.9.1 Laboratory testing of gas samples	75
5.9.2 Gas generation tests	76
5.9.3 Carbon content and other soil and groundwater tests	77
5.9.4 Carbon dating	80
5.10 Future directions: continuous monitoring	80
<b>6 Assessment of results</b>	<b>84</b>
6.1 General considerations	84
6.2 Conceptual model	84
6.3 Analysis of ground gas data	86
6.3.1 Outliers and anomalies	86
6.3.2 Graphs	86
6.3.3 Plotting contours	87
6.3.4 Statistical analysis	89
6.3.5 Temperature	89
6.3.6 As-built conditions	89
6.4 Analysis of vapour data	89
6.5 Tier 1 risk assessment: Is there a linkage?	90
6.6 Tier 2 risk assessment: qualitative assessment for methane and carbon dioxide	94
6.6.1 Gas screening value	94
6.7 Screening process	95
6.7.1 NHBC approach (Situation B in CIRIA C659/665)	96

---

6.7.2 Wilson and Card approach (Situation A in CIRIA C659/665)	96
6.7.3 Differences between Situation A and Situation B methods	97
6.8 Tier 3 risk assessment: quantitative assessment for methane and carbon dioxide	98
6.8.1 Entry of gas into building	102
6.8.2 Failure of subfloor ventilation	105
6.8.3 Justification of parameters and sensitivity analysis	107
6.8.4 Limitations and considerations of fault tree analysis	110
6.8.5 Common mistakes in fault tree risk assessments	111
6.9 Assessments for house extensions	111
6.10 Putting ground gas risk in context	112
6.11 Nuisance from ground gas: odours	114
6.12 Tier 2 and 3 assessment of vapours and trace gases	114
<b>7 Methods of gas protection</b>	<b>116</b>
7.1 In ground vertical barriers or venting systems	118
7.2 Building protection	123
7.3 Floor slabs and gas-resistant membranes	124
7.4 Passive ventilation below buildings	133
7.5 Active venting below buildings	141
7.6 Positive pressurisation below buildings	141
7.7 Gas monitoring and alarm systems	142
<b>8 Design of protection measures</b>	<b>147</b>
8.1 Defining the scope of gas protection	147
8.2 Low-rise housing with gardens (Situation B in CIRIA C659/665)	148
8.3 All other types of development (Situation A in CIRIA C659/665)	150
8.3.1 Membranes and the use of Table 8.1	151
8.4 British Standard BS 8485	152
8.5 Key points for design of gas protection systems	158
8.6 Detailed analysis of venting and positive pressurisation systems	159
8.6.1 Passive venting of voids	159

8.6.2 Estimating passive ventilation performance	161
8.6.3 Open void	162
8.6.4 Void formers	164
8.6.5 Basement car parks	165
8.6.6 Active ventilation sizing	166
8.6.7 Positive underfloor pressurisation	167
<b>9 Construction and validation</b>	<b>170</b>
9.1 Design report	170
9.2 Common problems with installation	170
9.3 Validation	172
9.3.1 Post-construction monitoring	173
<b>10 Maintenance</b>	<b>176</b>
<b>Appendix</b>	<b>177</b>
<b>Bibliography</b>	<b>194</b>
<b>Index</b>	<b>200</b>

The following figures can be found in the colour section between pages 148 and 149.

**Key to colour section**

Figure 5.2	Page i–ii	Figure 8.3	Page xi
Table 5.3	Page iii	Figure 8.4	Page xi
Table 6.4	Page iv	Figure 9.1	Page xii
Table 6.5	Page v	Figure 9.2	Page xii
Box 6.4	Page vi	Figure 9.3	Page xii
Figure 7.13	Page vii	Figure 9.4	Page xii
Table 8.1	Page viii–x	Figure 9.5	Page xii